


Maytag LAT8626AAM 04 - CONTROL PANEL



Maytag [Residential Maytag LAT8626AAM Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	22001619		Tube, Water Level Switch
2	22001665			Insert, Timer Knob
3	22001745		Not Available	PANEL, CONTROL (ALM)
4	22001791	22003875		Button- SW
"	22001790	22003876		Button- SW
"	22001784			Switch, Water Temp.
5	211605			Bezel, Timer Dial
6	22001662	8534058		Screw
7	22001757			Wire Harness, Main
"	22002208		Not Available	HARNES, WIRE
8	22001661	3400094		Screw, 10-32 X 3/8
"	22002186			Timer
"	22001691			Timer
9	22001668		Not Available	BEZEL, TIMER KNOB (ALM)
10	22001659			Timer Knob - Grey
11	211065			Spring, Index Wheel

12	22001778		Not Available	SWITCH, WATER LEVEL (INF.-ALM)
13	22001786			Switch, Rinse
"	22001790	22003876		Button- SW
14	22001765		Not Available	MANUAL, USE & CARE
"	22001771		Not Available	MANUAL, USE & CARE (FRENCH)
"	16000327		Not Available	GUIDE, QUICK REF. - MAYTAG

