


# Maytag LAT8626AAM 05 - TOP



Maytag [Residential Maytag LAT8626AAM Washer Parts](#) Parts Diagram 05 - TOP  
 Click on the part number to view part

| Item | Original Part Number     | Replaced By             | Status        | Part Description                            |
|------|--------------------------|-------------------------|---------------|---|
| 1    | <a href="#">211726</a>   |                         |               | Hinge, Ball Lid                             |
| 2    | <a href="#">22001298</a> |                         |               | Cap, Top Cover                              |
| "    | 207159                   | <a href="#">489355</a>  |               | Screw, 8 X 1/2                              |
| 3    | <a href="#">207167</a>   |                         |               | Block, Fuse                                 |
| "    | W10124350                |                         | Not Available | NOT REQUIRED PART OR SEE NOTE               |
| 4    | <a href="#">22002135</a> |                         |               | Bracket, Unbalance                          |
| "    | 22001645                 |                         | Not Available | BRACKET, UNBALANCE---NA                     |
| 5    | W10124350                |                         | Not Available | NOT REQUIRED PART OR SEE NOTE               |
| "    | <a href="#">207166</a>   |                         |               | Switch, Check                               |
| 6    | <a href="#">22001671</a> |                         |               | Console ---NA                               |
| 7    | <a href="#">213720</a>   |                         |               | Spring, Lid Switch                          |
| 8    | <a href="#">211881</a>   |                         |               | Grommet, Cord Part Not Used-Gas Models Only |
| 9    | 22001662                 | <a href="#">8534058</a> |               | Screw                                       |
| "    | 216423                   | <a href="#">3370225</a> |               | Screw                                       |

|    |                          |                          |  |
|----|--------------------------|--------------------------|--|
| "  | <a href="#">22001814</a> |                          | Back Panel, Console                            |
| 10 | 22001673                 | <a href="#">22001682</a> | Switch Assembly, Lid W/4amp Fuse               |
| "  | W10124350                |                          | Not Available<br>NOT REQUIRED PART OR SEE NOTE |
| 11 | <a href="#">22001672</a> |                          | Lever, Unbalance                               |
| "  | <a href="#">22001968</a> |                          | Lever, Unbalance                               |
| 12 | Y705026                  | <a href="#">3370225</a>  | Screw  |
| "  | <a href="#">22001654</a> |                          | Wire, Ground                                   |
| 13 | 22001675                 |                          | Not Available<br>LID W/LEGEND (ALM)            |
| "  | 22001677                 |                          | Not Available<br>LID W/LEGEND (CANADA-ALM)--NA |
| 14 | <a href="#">212716</a>   |                          | Bumper, Lid                                    |
| 15 | 22001967                 | <a href="#">12001908</a> | Switch-Lid                                     |
| "  | 205415                   | <a href="#">279347</a>   | Switch-Lid                                     |
| 16 | <a href="#">216255</a>   |                          | Plunger, Lid Switch                            |
| 17 | <a href="#">211500</a>   |                          | Washer, Bracket To Top Cover                   |
| 18 | W10124350                |                          | Not Available<br>NOT REQUIRED PART OR SEE NOTE |
| "  | <a href="#">22001678</a> |                          | Bracket, Switch And Fuse                       |
| 19 | 208194                   | <a href="#">22003062</a> | Cord, Power                                    |
| 20 | 22001402                 | <a href="#">214354</a>   | Screw, Top Cover To Cabnt.                     |
| 21 | 207159                   | <a href="#">489355</a>   | Screw, 8 X 1/2                                 |
| 22 | Y705026                  | <a href="#">3370225</a>  | Screw  |
| 23 | 216423                   | <a href="#">3370225</a>  | Screw  |
| 24 | <a href="#">213501</a>   |                          | Screw, No.6-20 X 1-1/8 Inch                    |
| 25 | <a href="#">Y311711</a>  |                          | Screw, Fuse Block                              |
| 26 | 216423                   | <a href="#">3370225</a>  | Screw  |
| 27 | 22001600                 | <a href="#">25-7809</a>  | Screw, No.6-20 1/2 Flthd Torx                  |
| 28 | <a href="#">22001352</a> |                          | Screw, Check Switch                            |
| 29 | 22001782                 | <a href="#">22002146</a> | Cover Assembly, Top                            |
| 30 | <a href="#">22001681</a> |                          | Unbalance Lever Assembly                       |
| "  | <a href="#">22001969</a> |                          | Unbalance Lever Assembly                       |
| 31 | W10124350                |                          | Not Available<br>NOT REQUIRED PART OR SEE NOTE |
| "  | <a href="#">22001682</a> |                          | Switch Assembly, Lid W/4amp Fuse               |
| 32 | 215374                   |                          | Not Available<br>GASKET FOR BLEACH CUP         |
| 33 | <a href="#">22001008</a> |                          | Cup, Bleach                                    |

