


# Maytag LAT8706AAM 04 - CONTROL PANEL



Maytag [Residential Maytag LAT8706AAM Washer Parts](#) Parts Diagram 04 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	<a href="#">22001619</a>		Tube, Water Level Switch
2	<a href="#">22001665</a>			Insert, Timer Knob
3	<a href="#">22001747</a>			Panel, Control
4	22001791	<a href="#">22003875</a>		Button- SW
"	22001790	<a href="#">22003876</a>		Button- SW
"	<a href="#">22001784</a>			Switch, Water Temp.
6	<a href="#">211605</a>			Bezel, Timer Dial
7	22001662	<a href="#">8534058</a>		Screw
8	<a href="#">22001757</a>			Wire Harness, Main
"	22002208		Not Available	HARNES, WIRE
9	<a href="#">22001692</a>			Timer
"	22001661	<a href="#">3400094</a>		Screw, 10-32 X 3/8
"	<a href="#">22002187</a>			Timer
10	22001668		Not Available	BEZEL, TIMER KNOB (ALM)
11	<a href="#">22001659</a>			Timer Knob - Grey
12	<a href="#">211065</a>			Spring, Index Wheel

13	22001778		Not Available	SWITCH, WATER LEVEL (INF.-ALM)
14	<a href="#">22001786</a>			Switch, Rinse
"	22001790	<a href="#">22003876</a>		Button- SW
15	22001771		Not Available	MANUAL, USE & CARE (FRENCH)
"	22001765		Not Available	MANUAL, USE & CARE

