


# Maytag LAT8824AAE 04 - CONTROL PANEL



Maytag [Residential Maytag LAT8824AAE Washer Parts](#) Parts Diagram 04 - CONTROL PANEL  
 Click on the part number to view part

| Item | Original Part Number     | Replaced By                 | Status        | Part Description                     |
|------|--------------------------|-----------------------------|---------------|--------------------------------------|
| 1    | 22001036                 | <a href="#">22001619</a>    |               | Tube, Water Level Switch             |
| 2    | <a href="#">204807</a>   |                             |               | Ground Wire, Supp. Plte To Top Cover |
| "    | <a href="#">22001133</a> |                             |               | Plate, Support                       |
| "    | 315483                   | <a href="#">3370225</a>     |               | Screw                                |
| 3    | 216250                   | <a href="#">22001446</a>    |               | Cap, Knob                            |
| 4    | 410296                   | <a href="#">596669</a>      |               | Clamp, Manifold                      |
| 5    | <a href="#">22001334</a> |                             |               | Panel, Control                       |
| 6    | <a href="#">214897</a>   |                             |               | Pad, Control Panel                   |
| 7    | 22001215                 | <a href="#">7730P011-60</a> |               | Lens, Indicator Light                |
| 8    | <a href="#">22001291</a> |                             |               | End Cap, Control Panel               |
| "    | 22001289                 |                             | Not Available | END CAP, CTRL. PNL. (LT-WHT)         |
| "    | <a href="#">22001564</a> |                             |               | Cap, End                             |
| "    | 22001565                 |                             | Not Available | CAP, END (LT-WHT)                    |
| 9    | <a href="#">214894</a>   |                             |               | Fastener, End Cap                    |
| 10   | <a href="#">214872</a>   |                             |               | Palnut, End Cap Note: Nut,           |

|    |                          |                           |  |
|----|--------------------------|---------------------------|--|
| 10 | <a href="#">214972</a>   |                           | Lamp Holder  |
| 11 | <a href="#">211605</a>   |                           | Bezel, Timer Dial                                  |
| 12 | <a href="#">210932</a>   |                           | Screw, No.8 X 9/16 Ctsk Note:<br>Screw, Inlet Duct |
| 13 | 211168                   | <a href="#">W10139210</a> | Screw, 8-18 X 5/16                                 |
| 14 | <a href="#">22001135</a> |                           | Switch, Rocker                                     |
| 15 | <a href="#">216412</a>   |                           | Screw, Bracket To Timer                            |
| 16 | <a href="#">903115</a>   |                           | Lock Light   |
| 17 | <a href="#">22001024</a> |                           | Timer  |
| 18 | <a href="#">22001265</a> |                           | Bezel, Timer Knob                                  |
| 19 | 22001198                 | Not Available             | KNOB, TIMER (WHT)                                  |
| 20 | <a href="#">211065</a>   |                           | Spring, Index Wheel                                |
| 21 | 208286                   | Not Available             | SWITCH, INFINITE (WHT)                             |
| 22 | 22001214                 | Not Available             | SWITCH, WATER TEMP.<br>(WHT)                       |
| 23 | <a href="#">22001333</a> |                           | Wire Harness, Main                                 |
| 24 | <a href="#">22001212</a> |                           | Switch, Speed                                      |

