


Maytag LAT8826AAM 04 - CONTROL PANEL



Maytag [Residential Maytag LAT8826AAM Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	22001619		Tube, Water Level Switch
2	22001665			Insert, Timer Knob
3	22001750		Not Available	PANEL, CONTROL (ALM)
4	22001784			Switch, Water Temp.
"	22001790	22003876		Button- SW
"	22001791	22003875		Button- SW
5	22001791	22003875		Button- SW
"	22001796			Switch, Speed Control
"	22001790	22003876		Button- SW
6	211605			Bezel, Timer Dial
7	22001662	8534058		Screw
8	22001760			Wire Harness, Main
"	22001948			Lens, Indicator Light
"	903115			Lock Light
"	22002211			Harness, Wire
9	22001661	3400094		Screw, 10-32 X 3/8

"	22002189	22004262	Timer
"	22001694		Timer
10	22001668	Not Available	BEZEL, TIMER KNOB (ALM)
11	22001659		Timer Knob - Grey
12	211065		Spring, Index Wheel
13	22001778	Not Available	SWITCH, WATER LEVEL (INF.-ALM)
14	22001790	22003876	Button- SW
"	22001791	22003875	Button- SW
"	22001909		Switch, Option
15	22002421	Not Available	MANUAL, USE & CARE
"	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG
"	22001772	Not Available	MANUAL, USE & CARE (FRENCH)

