


# Maytag LAT9200BAM 04 - CONTROL PANEL (WHT/WHT & ALM/ALM)



Maytag Residential Maytag LAT9200BAM Washer Parts Parts Diagram 04 - CONTROL PANEL (WHT/WHT & ALM/ALM)

[Click on the part number to view part](#)

| Item | Original Part Number   | Replaced By               | Status        | Part Description                                |
|------|------------------------|---------------------------|---------------|---|
| 1    | 212942                 | <a href="#">22001619</a>  |               | Tube, Water Level Switch                        |
| 2    | <a href="#">214818</a> |                           |               | Back Up Plate                                   |
| 3    | 315523                 |                           | Not Available | CAP, KNOB                                       |
| 4    | 410296                 | <a href="#">596669</a>    |               | Clamp, Manifold                                 |
| 5    | 208328                 |                           | Not Available | CONTROL PANEL, FACIA                            |
| 6    | <a href="#">214897</a> |                           |               | Pad, Control Panel                              |
| 7    | Y308652                |                           | Not Available | END CAP (R-H)                                   |
| "    | <a href="#">308651</a> |                           |               | End Cap   |
| 8    | <a href="#">214894</a> |                           |               | Fastener, End Cap                               |
| 9    | <a href="#">214872</a> |                           |               | Palnut, End Cap Note: Nut, Lamp Holder          |
| 10   | <a href="#">211605</a> |                           |               | Bezel, Timer Dial                               |
| 11   | <a href="#">210932</a> |                           |               | Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct |
| 12   | 211168                 | <a href="#">W10139210</a> |               | Screw, 8-18 X 5/16                              |
| 13   | 213966                 | <a href="#">3400014</a>   |               | Screw   |

|    |                        |                          |                     |
|----|------------------------|--------------------------|---------------------|
| 14 | <a href="#">211065</a> |                          | Spring, Index Wheel |
| 15 | <a href="#">207378</a> |                          | Timer               |
| 16 | <a href="#">216210</a> |                          | Skirt               |
| 17 | 216209                 | Not Available            | KNOB                |
| 18 | 205033                 | <a href="#">22205033</a> | Motor- Tim          |
| 19 | 208331                 | Not Available            | SWITCH (4LEVEL)     |
| 20 | <a href="#">208332</a> |                          | Switch              |
| "  | 213117                 | <a href="#">67006908</a> | Screw, Ice Rack     |
| 21 | 208122                 | Not Available            | WIRE HARNESS        |

