


Maytag LAT9200BBM 05 - TOP (WHT/WHT & ALM/ALM)



Maytag Residential Maytag LAT9200BBM Washer Parts Parts Diagram 05 - TOP (WHT/WHT & ALM/ALM)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	211726			Hinge, Ball Lid
2	207172L			Top Cover Assembly ALM---NA
3	207167			Block, Fuse
4	214279	204968		Plunger And Bracket Assembly--W
5	207166			Switch, Check
6	205635L		Not Available	CONSOLE (ALM)
7	213720			Spring, Lid Switch
8	912012	3400409		Screw
9	215075			Fastener, Control Panel To Console
10	207168	22001682		Switch Assembly, Lid W/4amp Fuse
11	215704			Lever, Unbalance
12	301548			Clamp, Ground Wire
13	311155			Ground Wire And Clamp
14	216073L		Not Available	(ALMOND)---NA

15	212716		Bumper, Lid
16	205415	279347	Switch-Lid
17	215700		Not Available
18	211500		LID SWITCH PLUNGER
19	Y215699	22001678	Washer, Bracket To Top Cover
20	204590		Bracket, Switch And Fuse
"	211881		Cord, Power
21	204445		Grommet, Cord Part Not Used- Gas Models Only
22	207159	489355	Screw And Fastener Assembly
23	210186	3370225	Screw, 8 X 1/2
24	211294	90767	Screw
25	213501		Screw, 8A X 3/8 HeX Washer Head Tapping
26	215705	Y311711	Screw, No.6-20 X 1-1/8 Inch
27	Y313559		Screw, Fuse Block
28	910182	25-7809	Screw
			Screw, No.6-20 1/2 Flthd Torx

