


# Maytag LAT9200BBM 07 - TUB (WHT/WHT & ALM/ALM)



Maytag Residential Maytag LAT9200BBM Washer Parts Parts Diagram 07 - TUB (WHT/WHT & ALM/ALM)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">207228</a>			Agitator W/Lock Screw
2	212942	<a href="#">22001619</a>		Tube, Water Level Switch
3	<a href="#">211130</a>			Bearing Liner, Tub Bearing
4	200744	<a href="#">W10175939</a>		Bolt
"	205254	<a href="#">W10175938</a>		Bolt
5	<a href="#">205529</a>			Nut And Bolt Kit For Tub Clam
6	<a href="#">215232</a>			Bumper, Unbalance
7	<a href="#">214725</a>			Cap For Spout-Outer Tub
8	<a href="#">211641</a>			Clamp, 1-1/16"
9	<a href="#">200846</a>			Clamp - Tub Cover
10	410296	<a href="#">596669</a>		Clamp, Manifold
11	211047	<a href="#">6-2110472</a>		Nut- Clamp
12	206380		Not Available	COVER, TUB
13	<a href="#">215721</a>			Dispensing Cap
14	<a href="#">215733</a>			Dispensing Cup
15	<a href="#">207219</a>			Filter, Self-Cleaning

16	<a href="#">213045</a>		Hose, Outer Tub Part Not Used
17	200900	<a href="#">616099</a>	Clamp
18	<a href="#">201575</a>		Clamp, Hose
19	202515	<a href="#">596669</a>	Clamp, Manifold
20	202574	<a href="#">3367052</a>	Clamp, Hose
21	213016	<a href="#">216201</a>	Nozzle
22	<a href="#">Y215234</a>		Hose, Injector Fill
23	<a href="#">213013</a>		Hose, Injector
24	<a href="#">213015</a>		Nozzle, Injector
25	<a href="#">215235</a>		Tube, Injector
26	207831	Not Available	TUB, INNER (W/PLUG)
28	<a href="#">Y015667</a>		Retaining Ring
29	<a href="#">Y054867</a>		Washer, Lock
30	<a href="#">205613</a>		Water Valve
31	204012	<a href="#">6-2095720</a>	Mounting S
32	<a href="#">205484</a>		Tub, Outer Part Not Used
33	<a href="#">215980</a>		Plug, Filter Hole
34	<a href="#">Y015666</a>		Washer, Retaining -
35	206478	Not Available	SCREW & WASHER FOR AGITATOR
36	<a href="#">312620</a>		Screw, Sems
37	211618	<a href="#">22001423</a>	Set Screw, Mounting Stem
38	<a href="#">211232</a>		Seal, Tub Cover
39	Y0A4298	<a href="#">6-0A57420</a>	Seal- Agitator
40	<a href="#">211100</a>		Washer, Outer Tub
41	<a href="#">215233</a>		Seal For Injector Tube
42	<a href="#">215447</a>		Sleeve For Injector
43	214739	<a href="#">596669</a>	Clamp, Manifold
44	200824	<a href="#">6-2040130</a>	Tub Bearin
45	204013	<a href="#">6-2040130</a>	Tub Bearin
46	<a href="#">211210</a>		Washer, Clamping Nut

