


Maytag LAT9200DAL 04 - CONTROL PANEL



Maytag [Residential Maytag LAT9200DAL Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	212942	22001619		Tube, Water Level Switch
2	214818			Back Up Plate
3	215821		Not Available	CAP, KNOB
4	410296	596669		Clamp, Manifold
5	208114			Facia A9200
6	214897			Pad, Control Panel
7	207215		Not Available	END CAP LH
8	207216		Not Available	END CAP RH
9	214894			Fastener, End Cap
10	214872			Palnut, End Cap Note: Nut, Lamp Holder
11	211605			Bezel, Timer Dial
12	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
13	211168	W10139210		Screw, 8-18 X 5/16
14	213117	67006908		Screw, Ice Rack
15	213966	3400014		Screw

16	211065		Spring, Index Wheel
17	207379		Timer
"	207378		Timer
18	215827	Not Available	TIMER DIAL SKIRT
19	215828		Knob, Timer
20	205033	22205033	Motor- Tim
21	207361		4 Level Pressure Switch
22	207368	Not Available	TEMP CONTROL SWITCH - 3 BUTTON
"	207367	Not Available	TEMP CONTROL SWITCH - 4 BUTTON
23	208122	Not Available	WIRE HARNESS
"	207383		Wire Harness

the laundry company[®]

the laundry company[®]

the laundry company[®]