


# Maytag LAT9306AGE 04 - CONTROL PANEL



Maytag [Residential Maytag LAT9306AGE Washer Parts](#) Parts Diagram 04 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	<a href="#">22001619</a>		Tube, Water Level Switch
2	<a href="#">22001664</a>			Timer Knob Insert/Cap
3	22001838		Not Available	PANEL, CONTROL (WHT)
4	<a href="#">22001942</a>			Washer, Sealing
"	<a href="#">22001663</a>			Knob, Selector Switch
5	<a href="#">211605</a>			Bezel, Timer Dial
6	22001662	<a href="#">8534058</a>		Screw
7	22001661	<a href="#">3400094</a>		Screw, 10-32 X 3/8
8	<a href="#">22001839</a>			Wire Harness, Main
"	<a href="#">22002218</a>			Harness, Wire
9	<a href="#">22001944</a>			Sealing Washer, Timer
"	22001943		Not Available	SHIELD, TIMER
"	<a href="#">22001863</a>			Timer RPR
"	<a href="#">22002192</a>			Timer
10	<a href="#">22001660</a>			Dial Skirt - White
11	<a href="#">22001659</a>			Timer Knob - Grey

12	<a href="#">211065</a>		Spring, Index Wheel
13	<a href="#">22001896</a>		Switch, Water Level
14	<a href="#">22001843</a>		Switch, Water Temp.
15	16009149	Not Available	MANUAL, USE & CARE
16	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG

