


# Maytag LAT9357AAE 04 - CONTROL PANEL



Maytag [Residential Maytag LAT9357AAE Washer Parts](#) Parts Diagram 04 - CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	<a href="#">22001619</a>		Tube, Water Level Switch
2	<a href="#">22001664</a>			Timer Knob Insert/Cap
3	<a href="#">22002407</a>			Panel, Control
4	<a href="#">22001663</a>			Knob, Selector Switch
5	<a href="#">211605</a>			Bezel, Timer Dial
6	22001662	<a href="#">8534058</a>		Screw
7	22001661	<a href="#">3400094</a>		Screw, 10-32 X 3/8
8	<a href="#">22002395</a>			Harness, Main Wire
9	22002200	<a href="#">22003361</a>		Timer
"	<a href="#">22003361</a>			Timer
10	<a href="#">22001660</a>			Dial Skirt - White
11	<a href="#">22001659</a>			Timer Knob - Grey
12	<a href="#">211065</a>			Spring, Index Wheel
13	<a href="#">22001656</a>			5 Level Rotary Pressure Switch
14	<a href="#">22001655</a>			Switch, Water Temp.
15	<a href="#">22001794</a>			Switch, Rotary

16	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG
17	22003931	Not Available	USE & CARE MANUEL
18	22002396	Not Available	MANUAL, USE & CARE (FRENCH)

