


# Maytag LAT9357AAM 04 - CONTROL PANEL



Maytag [Residential Maytag LAT9357AAM Washer Parts](#) Parts Diagram 04 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	<a href="#">22001619</a>		Tube, Water Level Switch
2	<a href="#">22001665</a>			Insert, Timer Knob
3	22002408		Not Available	PANEL, CONTROL (ALM)
4	22001667	<a href="#">22002589</a>		Knob, Selector
5	<a href="#">211605</a>			Bezel, Timer Dial
6	22001662	<a href="#">8534058</a>		Screw
7	22001661	<a href="#">3400094</a>		Screw, 10-32 X 3/8
8	<a href="#">22002395</a>			Harness, Main Wire
9	22002200	<a href="#">22003361</a>		Timer
10	22001668		Not Available	BEZEL, TIMER KNOB (ALM)
11	<a href="#">22001659</a>			Timer Knob - Grey
12	<a href="#">211065</a>			Spring, Index Wheel
13	<a href="#">22001656</a>			5 Level Rotary Pressure Switch
14	<a href="#">22001655</a>			Switch, Water Temp.
15	<a href="#">22001794</a>			Switch, Rotary

16 16000327

Not Available

GUIDE, QUICK REF. -  
MAYTAG

18 22002396

Not Available

MANUAL, USE & CARE  
(FRENCH)

