


# Maytag LAT9593ABW 07 - TUB



Maytag [Residential Maytag LAT9593ABW Washer Parts](#) Parts Diagram 07 - TUB  
 Click on the part number to view part

| Item | Original Part Number   | Replaced By               | Status | Part Description              |
|------|------------------------|---------------------------|--------|-------------------------------|
| 1    | <a href="#">207228</a> |                           |        | Agitator W/Lock Screw         |
| 2    | 212942                 | <a href="#">22001619</a>  |        | Tube, Water Level Switch      |
| 3    | <a href="#">211130</a> |                           |        | Bearing Liner, Tub Bearing    |
| 4    | 200744                 | <a href="#">W10175939</a> |        | Bolt                          |
| "    | 205254                 | <a href="#">W10175938</a> |        | Bolt                          |
| 5    | <a href="#">205529</a> |                           |        | Nut And Bolt Kit For Tub Clam |
| 6    | <a href="#">215232</a> |                           |        | Bumper, Unbalance             |
| 7    | <a href="#">214725</a> |                           |        | Cap For Spout-Outer Tub       |
| 8    | <a href="#">211641</a> |                           |        | Clamp, 1-1/16"                |
| 9    | <a href="#">200846</a> |                           |        | Clamp - Tub Cover             |
| 10   | 410296                 | <a href="#">596669</a>    |        | Clamp, Manifold               |
| 11   | 211047                 | <a href="#">6-2110472</a> |        | Nut- Clamp                    |
| 12   | <a href="#">211210</a> |                           |        | Washer, Clamping Nut          |
| 13   | <a href="#">215721</a> |                           |        | Dispensing Cap                |
| 14   | <a href="#">215733</a> |                           |        | Dispensing Cup                |
| 15   | <a href="#">207219</a> |                           |        | Filter, Self-Cleaning         |

|    |                         |                           |                               |
|----|-------------------------|---------------------------|-------------------------------|
| 16 | <a href="#">213045</a>  |                           | Hose, Outer Tub Part Not Used |
| 17 | 200900                  | <a href="#">616099</a>    | Clamp                         |
| 18 | <a href="#">201575</a>  |                           | Clamp, Hose                   |
| 19 | 202515                  | <a href="#">596669</a>    | Clamp, Manifold               |
| 20 | 202574                  | <a href="#">3367052</a>   | Clamp, Hose                   |
| 21 | 204013                  | <a href="#">6-2040130</a> | Tub Bearin                    |
| 22 | <a href="#">Y215234</a> |                           | Hose, Injector Fill           |
| 23 | <a href="#">213013</a>  |                           | Hose, Injector                |
| 24 | <a href="#">213015</a>  |                           | Nozzle, Injector              |
| 25 | <a href="#">215235</a>  |                           | Tube, Injector                |
| 26 | 207831                  | Not Available             | TUB, INNER (W/PLUG)           |
| 27 | 213016                  | <a href="#">216201</a>    | Nozzle                        |
| 28 | <a href="#">Y015667</a> |                           | Retaining Ring                |
| 29 | <a href="#">Y054867</a> |                           | Washer, Lock                  |
| 30 | <a href="#">205613</a>  |                           | Water Valve                   |
| 31 | 204012                  | <a href="#">6-2095720</a> | Mounting S                    |
| 32 | <a href="#">205484</a>  |                           | Tub, Outer Part Not Used      |
| 33 | 206380                  | Not Available             | COVER, TUB                    |
| 34 | <a href="#">Y015666</a> |                           | Washer, Retaining -           |
| 35 | 206478                  | Not Available             | SCREW & WASHER FOR AGITATOR   |
| 36 | <a href="#">312620</a>  |                           | Screw, Sems                   |
| 37 | 211618                  | <a href="#">22001423</a>  | Set Screw, Mounting Stem      |
| 38 | <a href="#">211232</a>  |                           | Seal, Tub Cover               |
| 39 | Y0A4298                 | <a href="#">6-0A57420</a> | Seal- Agitator                |
| 40 | <a href="#">211100</a>  |                           | Washer, Outer Tub             |
| 41 | <a href="#">215233</a>  |                           | Seal For Injector Tube        |
| 42 | <a href="#">215447</a>  |                           | Sleeve For Injector           |
| 43 | 214739                  | <a href="#">596669</a>    | Clamp, Manifold               |
| 44 | 200824                  | <a href="#">6-2040130</a> | Tub Bearin                    |

