


Maytag LAT9606AGE 04 - CONTROL PANEL



Maytag [Residential Maytag LAT9606AGE Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	22001619		Tube, Water Level Switch
2	22001664			Timer Knob Insert/Cap
3	22001845			Panel, Control
4	22001788			Button, Switch
"	22001789			Button, Switch
"	22001950			Switch, Water Temp.
6	211605			Bezel, Timer Dial
7	22001662	8534058		Screw
8	22001846			Wire Harness, Main
"	22002220			Harness, Wire
9	22002193			Timer
"	22001661	3400094		Screw, 10-32 X 3/8
"	22001848			Timer
10	22001660			Dial Skirt - White
11	22001659			Timer Knob - Grey
12	211065			Spring, Index Wheel

13	22001850	Not Available	SWITCH, WATER LEVEL (INF.)
14	22001788		Button, Switch
"	22001951		Switch, Rinse
15	16009149	Not Available	MANUAL, USE & CARE
16	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG

