


Maytag LAT9606AGE 05 - TOP



Maytag [Residential Maytag LAT9606AGE Washer Parts](#) Parts Diagram 05 - TOP
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|--------------------------|---------------|----------------------------------|
| 1 | 211726 | | | Hinge, Ball Lid |
| 2 | 22001298 | | | Cap, Top Cover |
| " | 207159 | 489355 | | Screw, 8 X 1/2 |
| 3 | 207167 | | | Block, Fuse |
| 4 | 22001645 | | Not Available | BRACKET, UNBALANCE----NA |
| " | 22002135 | | | Bracket, Unbalance |
| 5 | 207166 | | | Switch, Check |
| 6 | 22001670 | | | Console |
| 7 | 213720 | | | Spring, Lid Switch |
| 8 | 22002532 | 216183 | | Grommet, Cord Export |
| 9 | 22001662 | 8534058 | | Screw |
| " | 216423 | 3370225 | | Screw |
| " | 22001814 | | | Back Panel, Console |
| 10 | 22001673 | 22001682 | | Switch Assembly, Lid W/4amp Fuse |
| 11 | 22001968 | | | Lever, Unbalance |

| | | | |
|----|--------------------------|--------------------------|---|
| " | 22001672 | | Lever, Unbalance |
| 12 | 22001654 | | Wire, Ground |
| " | Y705026 | 3370225 | Screw |
| 13 | 22001674 | 22001893 | Lid |
| 14 | 212716 | | Bumper, Lid |
| 15 | 205415 | 279347 | Switch-Lid |
| " | 22002383 | 22003813 | Lid Switch |
| 16 | 216255 | | Plunger, Lid Switch |
| 17 | 211500 | | Washer, Bracket To Top Cover |
| 18 | 22001678 | | Bracket, Switch And Fuse |
| 19 | 208746 | Not Available | CORD, POWER (EXPORT) |
| 20 | 22001402 | 214354 | Screw, Top Cover To Cabnt. |
| 21 | 207159 | 489355 | Screw, 8 X 1/2 |
| 22 | Y705026 | 3370225 | Screw |
| 23 | 216423 | 3370225 | Screw |
| 24 | 213501 | | Screw, No.6-20 X 1-1/8 Inch |
| 25 | Y311711 | | Screw, Fuse Block |
| 26 | 216423 | 3370225 | Screw |
| 27 | 22001600 | 25-7809 | Screw, No.6-20 1/2 Flthd Torx |
| 28 | 22001352 | | Screw, Check Switch |
| 29 | 22001781 | 22002145 | Cover Assembly, Top |
| 30 | 22001681 | | Unbalance Lever Assembly |
| " | 22001969 | | Unbalance Lever Assembly |
| 31 | 22001682 | | Switch Assembly, Lid W/4amp Fuse |
| " | 22001967 | 12001908 | Switch-Lid |
| 32 | 215374 | Not Available | GASKET FOR BLEACH CUP |
| 33 | 22001006 | | Cup, Bleach |
| 34 | 22001387 | Not Available | CHANNEL ASSY. |
| 35 | 211294 | 90767 | Screw, 8A X 3/8 HeX Washer Head Tapping |
| " | 201101 | | Capacitor |
| 36 | 22001396 | | Clip, Capacitor |

