


Maytag LAT9614AAE 05 - TOP



Maytag [Residential Maytag LAT9614AAE Washer Parts](#) Parts Diagram 05 - TOP
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	211726			Hinge, Ball Lid
2	207159	489355		Screw, 8 X 1/2
"	22001298			Cap, Top Cover
3	207167			Block, Fuse
4	216256		Not Available	BRACKET, UNBALANCE
5	207166			Switch, Check
6	205635			Console
7	213720			Spring, Lid Switch
8	211881			Grommet, Cord Part Not Used-Gas Models Only
9	215075			Fastener, Control Panel To Console
10	207168	22001682		Switch Assembly, Lid W/4amp Fuse
11	22001136			Lever, Unbalance
12	301548			Clamp, Ground Wire
13	311155			Ground Wire And Clamp

14	22001028	22001893	Lid
"	22001206	22001893	Lid
15	212716		Bumper, Lid
16	205415	279347	Switch-Lid
17	216255		Plunger, Lid Switch
18	211500		Washer, Bracket To Top Cover
19	Y215699	22001678	Bracket, Switch And Fuse
20	208194	22003062	Cord, Power
21	204445		Screw And Fastener Assembly
22	207159	489355	Screw, 8 X 1/2
23	315483	3370225	Screw
24	216423	3370225	Screw
25	213501		Screw, No.6-20 X 1-1/8 Inch
26	Y311711		Screw, Fuse Block
27	Y313559		Screw
28	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx
29	22001352		Screw, Check Switch
"	22001353		Set Screw, Motor Pulley
30	22001117	Not Available	TOP COVER ASSEMBLY (WHT)
31	22001311		Unbalance Lever Assembly
32	207176	22001682	Switch Assembly, Lid W/4amp Fuse

