


Maytag LAT9614AAL 05 - TOP



Maytag [Residential Maytag LAT9614AAL Washer Parts](#) Parts Diagram 05 - TOP
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	211726			Hinge, Ball Lid
2	207159	489355		Screw, 8 X 1/2
"	22001298			Cap, Top Cover
3	207167			Block, Fuse
4	216256		Not Available	BRACKET, UNBALANCE
5	207166			Switch, Check
6	205635L		Not Available	CONSOLE (ALM)
7	213720			Spring, Lid Switch
8	211881			Grommet, Cord Part Not Used-Gas Models Only
9	215075			Fastener, Control Panel To Console
10	207168	22001682		Switch Assembly, Lid W/4amp Fuse
11	22001136			Lever, Unbalance
12	301548			Clamp, Ground Wire
13	311155			Ground Wire And Clamp

14	22001029		Not Available	LID (CANADA-ALM)---NA
"	22001207		Not Available	LID W/LEGEND (ALM)---NA
15	212716			Bumper, Lid
16	205415	279347		Switch-Lid
17	216255			Plunger, Lid Switch
18	211500			Washer, Bracket To Top Cover
19	Y215699	22001678		Bracket, Switch And Fuse
20	208194	22003062		Cord, Power
21	204445			Screw And Fastener Assembly
22	207159	489355		Screw, 8 X 1/2
23	315483	3370225		Screw
24	216423	3370225		Screw
25	213501			Screw, No.6-20 X 1-1/8 Inch
26	Y311711			Screw, Fuse Block
27	Y313559			Screw
28	910182	25-7809		Screw, No.6-20 1/2 Flthd Torx
29	22001352			Screw, Check Switch
"	22001353			Set Screw, Motor Pulley
30	22001118		Not Available	TOP, MAIN (ALM)---NA
31	22001311			Unbalance Lever Assembly
32	207176	22001682		Switch Assembly, Lid W/4amp Fuse

