


Maytag LAT9615AAE 04 - CONTROL PANEL



Maytag [Residential Maytag LAT9615AAE Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	22001619		Tube, Water Level Switch
2	204807			Ground Wire, Supp. Plte To Top Cover
"	22001132			Plate, Support
"	315483	3370225		Screw
3	22001446			Cap, Knob
4	410296	596669		Clamp, Manifold
5	22001236			Panel, Control
6	214897			Pad, Control Panel
8	22001289		Not Available	END CAP, CTRL. PNL. (LT-WHT)
"	22001564			Cap, End
"	22001565		Not Available	CAP, END (LT-WHT)
"	22001291			End Cap, Control Panel
9	214894			Fastener, End Cap
10	214872			Palnut, End Cap Note: Nut, Lamp Holder

11	211605		Bezel, Timer Dial
12	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
13	211168	W10139210	Screw, 8-18 X 5/16
14	211168	W10139210	Screw, 8-18 X 5/16
15	216412		Screw, Bracket To Timer
17	22001026		Timer
"	22001515	Not Available	MOTOR, TIMER
18	22001265		Bezel, Timer Knob
19	22001198	Not Available	KNOB, TIMER (WHT)
20	211065		Spring, Index Wheel
21	208201		Switch, Pressure
22	208281	Not Available	SWITCH, TEMP (4POSITION)
23	22001314		Wire Harness, Main
24	22001268	Not Available	KNOB ASSY. (WHT)
25	22001499	22001622	Use And Care Manual
"	22001500	Not Available	MANUAL, USE & CARE
"	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG

