


# Maytag LAT9615AAM 06 - TRANSMISSION



Maytag [Residential Maytag LAT9615AAM Washer Parts](#) Parts Diagram 06 - TRANSMISSION  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">206628</a>			Cover, Transmission
2	207153	<a href="#">6-2097820</a>		Kit- Shaft
3	206713	<a href="#">6-2067130</a>		Gear- Beve
4	215410	<a href="#">12001450</a>		Ctr Shaft W/Collar Andkeeper- Dp
5	215415		Not Available	COLLAR, LOWER
6	206624	<a href="#">6-2097750</a>		Trans Dee
7	<a href="#">215394</a>			Washer, Bevel Gear
8	211483	<a href="#">6-2114830</a>		Washer- SP
9	206602	<a href="#">207843</a>		Lip Seal Repair Kit
10	<a href="#">Y206629</a>			Pin, Collar
11	215401	<a href="#">W10221114</a>		Pinion
12	<a href="#">215395</a>			Plate, Clutch
13	215417		Not Available	SCREW, TRANSMISSION COVER
14	<a href="#">210690</a>			Seal, Rubber
15	Y058700	<a href="#">675652</a>		Adhesive

16

[215581](#)

Spring, Agitator Shaft

17

206685

[6-2066850](#)

Yoke

18

206707

[6-2097750](#)

Trans Dee

