

# Maytag LAT9616AAM 06 - TRANSMISSION



Maytag [Residential Maytag LAT9616AAM Washer Parts](#) Parts Diagram 06 - TRANSMISSION  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">206628</a>			Cover, Transmission
2	22002415	<a href="#">6-2168983</a>		Shaft- Agi
"	207153	<a href="#">6-2097820</a>		Kit- Shaft
3	206713	<a href="#">6-2067130</a>		Gear- Beve
4	22002342	<a href="#">6-2300050</a>		Shaft- Cen
"	215410	<a href="#">12001450</a>		Ctr Shaft W/Collar Andkeeper- Dp
5	<a href="#">22002353</a>			Collar, Center Shaft
"	215415		Not Available	COLLAR, LOWER
6	22002416	<a href="#">6-2300100</a>		Assembly-
"	206624	<a href="#">6-2097750</a>		Trans Dee
7	<a href="#">215394</a>			Washer, Bevel Gear
8	211483	<a href="#">6-2114830</a>		Washer- SP
9	206602	<a href="#">207843</a>		Lip Seal Repair Kit
10	<a href="#">Y206629</a>			Pin, Collar
"	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE

11	215401	<a href="#">W10221114</a>		Pinion
12	<a href="#">215395</a>			Plate, Clutch
13	215417		Not Available	SCREW, TRANSMISSION COVER
"	215417		Not Available	SCREW, TRANSMISSION COVER
14	<a href="#">22002417</a>			O-Ring AgitatOr Shaft
"	<a href="#">210690</a>			Seal, Rubber
15	Y058700	<a href="#">675652</a>		Adhesive
16	<a href="#">215581</a>			Spring, Agitator Shaft
"	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
17	206685	<a href="#">6-2066850</a>		Yoke
18	<a href="#">22002340</a>			Collar, Agitator Shaft
19	<a href="#">22002341</a>			Collar, Lower Plastic Keeper
20	206707	<a href="#">6-2097750</a>		Trans Dee
"	22002126	<a href="#">6-2097750</a>		Trans Dee

