

Maytag LAT9616AAM 07 - TUB



Maytag [Residential Maytag LAT9616AAM Washer Parts](#) Parts Diagram 07 - TUB
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001821			Agitator Auger And Base Assembly
2	22001036	22001619		Tube, Water Level Switch
3	211130			Bearing Liner, Tub Bearing
4	200744	W10175939		Bolt
"	205254	W10175938		Bolt
5	22001299			Tub Cover And Gasket Assembly
6	Y22001201	22001007		Gasket, Cover To Tub
7	22001320			Tube, Bleach
8	211641			Clamp, 1-1/16"
9	22001142			Ring, Balance
10	211047	6-2110472		Nut- Clamp
11	22001805	21001905		Dispenser, Fabric
12	22001806	21001905		Dispenser, Fabric
13	207219			Filter, Self-Cleaning
14	213045			Hose, Outer Tub Part Not

14	213043		Used
15	22001640	285655	Clamp, Hose
16	22001819		L0cking Screw And O Ring
17	22001423		Set Screw, Mounting Stem
18	22001640	285655	Clamp, Hose
19	211210		Washer, Clamping Nut
20	200824	6-2040130	Tub Bearin
21	204013	6-2040130	Tub Bearin
22	22001139		Tub, Inner
23	205161	489503	Clamp
24	Y015667		Retaining Ring
25	Y054867		Washer, Lock
26	Y015666		Washer, Retaining -
27	22001114	Not Available	TUB, OUTER (EX. LARGE)
28	211100		Washer, Outer Tub
29	22001648	6-2095720	Mounting S
30	214434		Spout, Deflector

