


Maytag LAT9706AAM 04 - CONTROL PANEL (9706)



Maytag [Residential Maytag LAT9706AAM Washer Parts](#) Parts Diagram 04 - CONTROL PANEL (9706)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	22001619		Tube, Water Level Switch
2	22001665			Insert, Timer Knob
3	22001749		Not Available	PANEL, CONTROL (ALM)
4	22001784			Switch, Water Temp.
"	22001791	22003875		Button- SW
"	22001790	22003876		Button- SW
5	22001796			Switch, Speed Control
"	22001791	22003875		Button- SW
"	22001790	22003876		Button- SW
6	211605			Bezel, Timer Dial
7	22001662	8534058		Screw
8	903115			Lock Light
"	22001759			Wire Harness, Main
"	22001948			Lens, Indicator Light
"	22002210			Harness, Wire
9	22001694			Timer

"	22001661	3400094	Screw, 10-32 X 3/8
"	22002189	22004262	Timer
10	22001668		Not Available
			BEZEL, TIMER KNOB (ALM)
11	22001659		Timer Knob - Grey
12	211065		Spring, Index Wheel
13	22001778		Not Available
			SWITCH, WATER LEVEL (INF.-ALM)
14	22001790	22003876	Button- SW
"	22001791	22003875	Button- SW
"	22001909		Switch, Option
15	22002421		Not Available
			MANUAL, USE & CARE
"	16000327		Not Available
			GUIDE, QUICK REF. - MAYTAG

the laundry company[®]

the laundry company[®]

the laundry company[®]