


# Maytag LAT9804AAE 06 - TRANSMISSION



Maytag Residential Maytag LAT9804AAE Washer Parts Parts Diagram 06 - TRANSMISSION  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">206628</a>			Cover, Transmission
2	207153	<a href="#">6-2097820</a>		Kit- Shaft
3	206713	<a href="#">6-2067130</a>		Gear- Beve
4	215410	<a href="#">12001450</a>		Ctr Shaft W/Collar Andkeeper- Dp
5	215415		Not Available	COLLAR, LOWER
6	206624	<a href="#">6-2097750</a>		Trans Dee
7	<a href="#">215394</a>			Washer, Bevel Gear
8	211059	<a href="#">6-2301530</a>		Pulley
9	211483	<a href="#">6-2114830</a>		Washer- SP
10	206602	<a href="#">207843</a>		Lip Seal Repair Kit
11	<a href="#">Y206629</a>			Pin, Collar
12	215401	<a href="#">W10221114</a>		Pinion
13	<a href="#">215395</a>			Plate, Clutch
14	211090	<a href="#">22003555</a>		Washer, Stop Lug
15	211375	<a href="#">681582</a>		Screw
				SCREW, TRANSMISSION

16	215417	Not Available	SCREW, TRANSMISSION COVER
17	<a href="#">210690</a>		Seal, Rubber
18	Y058700	<a href="#">675652</a>	Adhesive
19	<a href="#">215581</a>		Spring, Agitator Shaft
20	<a href="#">211089</a>		Lug, Stop Pulley
21	206685	<a href="#">6-2066850</a>	Yoke
22	206707	<a href="#">6-2097750</a>	Trans Dee

