


Maytag LAT9806AKM 04 - CONTROL PANEL (LAT9806)



Maytag Residential Maytag LAT9806AKM Washer Parts Parts Diagram 04 - CONTROL PANEL (LAT9806)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	22001619		Tube, Water Level Switch
2	22001665			Insert, Timer Knob
3	22001752		Not Available	PANEL, CONTROL (ALM)
4	22001790	22003876		Button- SW
"	22001784			Switch, Water Temp.
"	22001791	22003875		Button- SW
5	22001791	22003875		Button- SW
"	22001798			Switch, Speed Control
"	22001790	22003876		Button- SW
6	211605			Bezel, Timer Dial
7	22001662	8534058		Screw
8	22001852			Wire Harness, Main
"	22002226			Wire Harness, Main
9	22002199			Timer
"	22001854			Timer
10	22001668		Not Available	BEZEL, TIMER KNOB (ALM)

11	22001659		Timer Knob - Grey
12	211065		Spring, Index Wheel
13	22001778	Not Available	SWITCH, WATER LEVEL (INF.-ALM)
14	22001791	22003875	Button- SW
"	22001790	22003876	Button- SW
"	22001792		Switch, Pushbutton
15	22001560	Not Available	MANUAL, USE & CARE

