


# Maytag LAT9806AKQ 04 - CONTROL PANEL (LAT9806)



Maytag Residential Maytag LAT9806AKQ Washer Parts Parts Diagram 04 - CONTROL PANEL (LAT9806)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	<a href="#">22001619</a>		Tube, Water Level Switch
2	<a href="#">33002347</a>			Timer Knob Insert/Cap
3	<a href="#">22002590</a>			Panel, Control
4	<a href="#">22002585</a>			Switch, Push Button
"	22002698	<a href="#">22003875</a>		Button- SW
"	<a href="#">22002697</a>			Button, Switch
5	<a href="#">22002586</a>			Switch, Push Button
"	<a href="#">22002697</a>			Button, Switch
"	22002698	<a href="#">22003875</a>		Button- SW
6	<a href="#">211605</a>			Bezel, Timer Dial
7	22001662	<a href="#">8534058</a>		Screw
8	<a href="#">22002226</a>			Wire Harness, Main
9	<a href="#">22002199</a>			Timer
10	22002598	<a href="#">22003920</a>		Dial Skirt
11	<a href="#">22001659</a>			Timer Knob - Grey
12	<a href="#">211065</a>			Spring, Index Wheel

13	22002588	Not Available	SWITCH, PRESSURE (BSQ)
14	<a href="#">22002697</a>		Button, Switch
"	<a href="#">22001792</a>		Switch, Pushbutton
"	22002698	<a href="#">22003875</a>	Button- SW
15	22001560	Not Available	MANUAL, USE & CARE

