


Maytag LAT9806AKQ 05 - TOP (LAT9806)



Maytag Residential Maytag LAT9806AKQ Washer Parts Parts Diagram 05 - TOP (LAT9806)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	211726			Hinge, Ball Lid
2	207159	489355		Screw, 8 X 1/2
"	22001298			Cap, Top Cover
3	207167			Block, Fuse
4	22002135			Bracket, Unbalance
5	207166			Switch, Check
6	22002616		Not Available	CONSOLE (BSQ)
"	22001671			Console ----NA
7	213720			Spring, Lid Switch
8	22002532	216183		Grommet, Cord Export
9	216423	3370225		Screw
"	22001662	8534058		Screw
"	22001814			Back Panel, Console
10	22001673	22001682		Switch Assembly, Lid W/4amp Fuse
11	22001968			Lever, Unbalance
12	22001654			Wire, Ground

"	Y705026	3370225	Screw
13	22002655	Not Available	LID, WITH LEGEND (BSQ)
14	212716		Bumper, Lid
15	22002383	22003813	Lid Switch
16	216255		Plunger, Lid Switch
17	211500		Washer, Bracket To Top Cover
18	22001678		Bracket, Switch And Fuse
19	22001558		Cord, Power
20	22001402	214354	Screw, Top Cover To Cabnt.
21	207159	489355	Screw, 8 X 1/2
22	Y705026	3370225	Screw
23	216423	3370225	Screw
24	213501		Screw, No.6-20 X 1-1/8 Inch
25	Y311711		Screw, Fuse Block
26	216423	3370225	Screw
27	22001600	25-7809	Screw, No.6-20 1/2 Flthd Torx
28	22001352		Screw, Check Switch
29	22002650		Cover, Top Assembly
30	22001969		Unbalance Lever Assembly
31	22001967	12001908	Switch-Lid
32	215374	Not Available	GASKET FOR BLEACH CUP
33	22002596	22001008	Cup, Bleach
34	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	22001857	201101	Capacitor
35	22001396		Clip, Capacitor

the laundry company®

the laundry company®