


Maytag LAT9824ABL 04 - CONTROL PANEL



Maytag [Residential Maytag LAT9824ABL Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	22001619		Tube, Water Level Switch
2	315483	3370225		Screw
"	204807			Ground Wire, Supp. Plte To Top Cover
"	22001133			Plate, Support
3	216193		Not Available	CAP, TIMER KNOB (BLK)
4	410296	596669		Clamp, Manifold
5	22001121		Not Available	PANEL, CONTROL (BLK)
6	214897			Pad, Control Panel
7	22001215	7730P011-60		Lens, Indicator Light
8	22001290			End Cap, Control Panel
"	22001288			End Cap, Control Panel
9	214894			Fastener, End Cap
10	214872			Palnut, End Cap Note: Nut, Lamp Holder
11	211605			Bezel, Timer Dial
12	311728	210022		Screw, No.8 X 9/16 Ctsk Note:

12	214120	21032	Screw, Inlet Duct
13	211168	W10139210	Screw, 8-18 X 5/16
14	22001134	22001135	Switch, Rocker
15	216412		Screw, Bracket To Timer
16	903115		Lock Light
17	22001023		Timer
18	22001264	Not Available	BEZEL, TIMER KNOB (BLK)
19	215828		Knob, Timer
20	211065		Spring, Index Wheel
21	208285	Not Available	SWITCH, INFINITE (BLK) SUB
22	22001209	Not Available	SWITCH, TEMPERATURE (BLK) OB
23	22001344	Not Available	WIRE HARNESS, MAIN
24	22001210		Switch, Speed
25	22001095	Not Available	MANUAL, USE & CARE

