


# Maytag LAT9824ABM 04 - CONTROL PANEL (LAT9824AAM & ABM)



Maytag [Residential Maytag LAT9824ABM Washer Parts](#) Parts Diagram 04 - CONTROL PANEL (LAT9824AAM & ABM)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	<a href="#">22001619</a>		Tube, Water Level Switch
2	<a href="#">204807</a>			Ground Wire, Supp. Plte To Top Cover
"	<a href="#">22001133</a>			Plate, Support
"	315483	<a href="#">3370225</a>		Screw
3	216424		Not Available	CAP, KNOB (ALM)
4	410296	<a href="#">596669</a>		Clamp, Manifold
5	22001452		Not Available	PANEL, CONTROL (ALM)
6	<a href="#">214897</a>			Pad, Control Panel
7	22001215	<a href="#">7730P011-60</a>		Lens, Indicator Light
8	<a href="#">22001293</a>			End Cap, Control Panel
"	22001292	<a href="#">22001567</a>		Cap, End
9	<a href="#">214894</a>			Fastener, End Cap
10	<a href="#">214872</a>			Palnut, End Cap Note: Nut, Lamp Holder
11	<a href="#">211605</a>			Bezel, Timer Dial
12	<a href="#">210032</a>			Screw, No.8 X 9/16 Ctsk Note:

12	<a href="#">210932</a>		Screw, Inlet Duct
13	211168	<a href="#">W10139210</a>	Screw, 8-18 X 5/16
14	22001282	<a href="#">22001135</a>	Switch, Rocker
15	<a href="#">216412</a>		Screw, Bracket To Timer
16	<a href="#">903115</a>		Lock Light
17	<a href="#">22001023</a>		Timer
18	22001266	Not Available	BEZEL, TIMER KNOB (ALM)
19	22001199	Not Available	KNOB ASSY. (ALM)
20	<a href="#">211065</a>		Spring, Index Wheel
21	22001454	Not Available	SWITCH, INFINITE (ALM)
22	22001455	Not Available	SWITCH, WATER TEMP. (ALM)
23	22001344	Not Available	WIRE HARNESS, MAIN
24	22001458	Not Available	SWITCH, SPEED CONTROL (ALM)
25	22001095	Not Available	MANUAL, USE & CARE

