


Maytag LAT9824AGE 04 - CONTROL PANEL



Maytag [Residential Maytag LAT9824AGE Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	22001619		Tube, Water Level Switch
2	22001133			Plate, Support
3	216250	22001446		Cap, Knob
4	410296	596669		Clamp, Manifold
5	22001420		Not Available	PANEL, CONTROL (WHT)
6	214897			Pad, Control Panel
7	22001215	7730P011-60		Lens, Indicator Light
8	22001291			End Cap, Control Panel
"	22001289		Not Available	END CAP, CTRL. PNL. (LT-WHT)
"	22001564			Cap, End
"	22001565		Not Available	CAP, END (LT-WHT)
9	214894			Fastener, End Cap
10	214872			Palnut, End Cap Note: Nut, Lamp Holder
11	211605			Bezel, Timer Dial
12	210032			Screw, No.8 X 9/16 Ctsk Note:

12	210932		Screw, Inlet Duct
13	211168	W10139210	Screw, 8-18 X 5/16
14	22001135		Switch, Rocker
15	216412		Screw, Bracket To Timer
16	22001403		Light, Indicator
17	22001421		Timer
"	22001612	Not Available	TIMER MOTOR (230-50)
18	22001265		Bezel, Timer Knob
19	22001198	Not Available	KNOB, TIMER (WHT)
20	211065		Spring, Index Wheel
21	208286	Not Available	SWITCH, INFINITE (WHT)
22	22001214	Not Available	SWITCH, WATER TEMP. (WHT)
23	22001422	Not Available	WIRE HARNESS, MAIN
24	22001213		Switch, Speed
25	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG
"	22001098	Not Available	MANUAL, USE & CARE

