


Maytag LAT9824AKM 04 - CONTROL PANEL



Maytag [Residential Maytag LAT9824AKM Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001036	22001619		Tube, Water Level Switch
2	22001133			Plate, Support
3	22001447		Not Available	CAP, KNOB (ALM)
4	410296	596669		Clamp, Manifold
5	22001557		Not Available	PANEL, CONTROL (ALM)
6	214897			Pad, Control Panel
7	22001215	7730P011-60		Lens, Indicator Light
8	22001567			Cap, End
"	22001566	22001293		End Cap, Control Panel
9	214894			Fastener, End Cap
10	214872			Palnut, End Cap Note: Nut, Lamp Holder
11	211605			Bezel, Timer Dial
12	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
13	211168	W10139210		Screw, 8-18 X 5/16
14	22001282	22001135		Switch, Rocker

15	216412		Screw, Bracket To Timer
16	22001403		Light, Indicator
17	22001559	Not Available	TIMER
18	22001266	Not Available	BEZEL, TIMER KNOB (ALM)
19	22001199	Not Available	KNOB ASSY. (ALM)
20	211065		Spring, Index Wheel
21	22001454	Not Available	SWITCH, INFINITE (ALM)
22	22001455	Not Available	SWITCH, WATER TEMP. (ALM)
23	22001411	Not Available	WIRE HARNESS, MAIN
24	22001458	Not Available	SWITCH, SPEED CONTROL (ALM)
25	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG
"	22001560	Not Available	MANUAL, USE & CARE

the laundry company[®]

the laundry company[®]

the laundry company[®]