


Maytag LAV3600AWW 04 - CONTROL PANEL



Maytag [Residential Maytag LAV3600AWW Washer Parts](#) Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001619			Tube, Water Level Switch
2	22001843			Switch, Water Temp.
3	22004260			Facia - White
4	22003913	22001663		Knob, Selector Switch
5	211065			Spring, Index Wheel
6	Y22002339	8534058		Screw
7	22001661	3400094		Screw, 10-32 X 3/8
8	22004261			Pressure Switch
9	22004262			Timer
10	22003914	22001660		Dial Skirt - White
11	22003915			Timer Knob
12	211605			Bezel, Timer Dial
13	22001664			Timer Knob Insert/Cap
14	22001794			Switch, Rotary
15	22002578			Switch, Speed