


# Maytag LDE18CA 03 - REAR VIEW



Maytag [Residential Maytag LDE18CA Dryer Parts](#) Parts Diagram 03 - REAR VIEW  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	<a href="#">62739</a>		Nut, Lock
002	<a href="#">210385</a>			Lock Nut For Adjustable Leg
003	<a href="#">210684</a>			Foot, Adjustable Leg
004	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
005	<a href="#">211881</a>			Grommet, Cord Part Not Used-Gas Models Only
006	NLA		Not Available	CONTROL COVER-WHITE
007	NLA		Not Available	CONTROL COVER-HARVEST WHEAT
008	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
009	Y302699	<a href="#">22003428</a>		Leg, Adjustable
010	NLA		Not Available	CONTROL CENTER-WHITE
011	NLA		Not Available	CABINET-WHITE
012	NLA		Not Available	CABINET-ALMOND
013	NLA		Not Available	CABINET-HARVEST WHEAT
014	Y303361		Not Available	BASE ASSY. (UPPER &

014	Y303301	Not Available	LOWER)
015	NLA	Not Available	TOP COVER-WHITE
016	NLA	Not Available	TOP COVER-ALMOND
017	NLA	Not Available	TOP COVER-HARVEST WHEAT
018	Y303442		EXHAUST DUCT ASSEMBLY
019	NLA	Not Available	SCREW & WASHER ASSY.
020	NLA	Not Available	CONTROL COVER-WHITE
021	NLA	Not Available	CONTROL COVER-ALMOND
022	NLA	Not Available	CONTROL COVER-HARVEST WHEAT
023	<a href="#">Y305086</a>		Adjustable Leg And Nut
024	<a href="#">310557</a>		Washer
025	Y310632	<a href="#">1163839</a>	Screw
026	NLA	Not Available	BACK FOR CONTROL PANEL
027	<a href="#">Y313559</a>		Screw
028	<a href="#">Y313561</a>		Screw---NA
029	<a href="#">Y314137</a>		Foot, Rubber

