


Maytag LDE22CS 04 - CONTROL CENTER SHROUD

MODELS DE-DG22CS

CONTROL CENTER SHROUD - CS



* Contact your commercial distributor for locks and keys

Maytag Residential Maytag LDE22CS Dryer Parts Parts Diagram 04 - CONTROL CENTER SHROUD

Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|---------------------------|---------------|---|
| 001 | Y014872 | | | Screw, Coin Meter Stop - |
| 002 | Y052740 | 62739 | | Nut, Lock |
| 003 | NLA | | Not Available | MTG. STRAP---NA |
| 004 | 205423 | 208883 | | Coin Box K |
| " | 205423L | 208883 | | Coin Box K |
| 005 | NLA | | Not Available | MAYTAG COIN SLIDE |
| 006 | 205663 | | | Knob For Selector Switch |
| 007 | 211168 | W10139210 | | Screw, 8-18 X 5/16 |
| 008 | 211294 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 009 | 212276 | W10116760 | | Screw |
| 010 | 212328 | W10139762 | | Hex Nut, 3/4-27 |
| 011 | NLA | | Not Available | SPRING WASHER FOR LOCK |
| 012 | 213648 | 98165 | | Screw |
| 013 | Y303204 | | | Start Switch With Nuts |
| 014 | Y303420 | | Not Available | SELECTOR SWITCH |

| | | | | |
|-----|-------------------------|--------------------------|---------------|-----------------------------|
| 015 | 303963 | | Not Available | LIGHT, INDICATOR |
| 016 | Y303981 | | | Ground Wire For Latch |
| 017 | NLA | | Not Available | COIN METER STOP WITH SCREWS |
| 018 | 305534 | | Not Available | VAULT ASSEMBLY |
| 019 | NLA | | Not Available | CONTROL SHROUD-WHITE |
| 020 | 305537 | | Not Available | OUTER CASE-WHITE |
| 021 | NLA | | Not Available | OUTER CASE-ALMOND |
| 022 | NLA | | Not Available | OUTER CASE (WHT) |
| 023 | NLA | | Not Available | SPANISH LABEL KIT |
| 024 | Y310632 | 1163839 | | Screw |
| 025 | Y312702 | | | Knurled Nut, Start Switch |
| 026 | Y312706 | 422617 | | Nut |
| 027 | 312751 | | | Lockwasher, Start Switch |
| 028 | NLA | | Not Available | INSULATOR |
| 029 | Y313424 | | | Screw, Vault Panel |
| 030 | Y313427 | 206637 | | Lock Kit |
| 031 | 313428 | | Not Available | PLATE FOR LATCH |
| 032 | Y313559 | | | Screw |
| 033 | Y313671 | 33001303 | | Grommet, Plate Hole |
| 034 | Y314261 | | | Switch And Relay Bracket |
| 035 | 314270 | | Not Available | CONTROL PANEL |
| 036 | 910768 | M0280301 | | Tie Electr |

