


# Maytag LDE382 02 - FRONT PANEL & DOOR ASSEMBLY



Maytag Residential Maytag LDE382 Dryer Parts Parts Diagram 02 - FRONT PANEL & DOOR ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">204439</a>			Screw And Fstner Assembly
2	212949	<a href="#">22001866</a>		Screw, Relay
3	212982	<a href="#">22001650</a>		Fastener, Spring
4	303942		Not Available	KNOB AND SCREW
5	Y304577	<a href="#">33001230</a>		Hinge, Door
6	304595	<a href="#">3369903</a>		Dishrack
7	304595L		Not Available	FRONT PANEL-ALMOND
8	304595M		Not Available	FRONT PANEL-HARVEST WHEAT
9	Y305753	<a href="#">W10169313</a>		Switch-Dor
10	<a href="#">306436</a>			Door Latch Kit--W
11	Y306668			DOOR (WHT)
12	306668L		Not Available	DOOR, ALMOND
13	306668M		Not Available	DOOR, HARVEST WHEAT
14	306676		Not Available	INNER DOOR WITH KNOB
15	<a href="#">Y310376</a>			Clip, Door Switch Harness

16	312301	Not Available	BUSHING FOR ACCESS STUD
17	<a href="#">312369</a>		Sleeve, Access Panel Stud Part Not Used
18	<a href="#">Y313907</a>		Fastener, Twin
19	Y313908		DOOR PANEL-WHITE
20	313908L	Not Available	DOOR PANEL-ALMOND
21	313908M	Not Available	DOOR PANEL-HARVEST WHEAT
22	<a href="#">Y313910</a>		Clip, Door Liner To Outer Panel
23	<a href="#">Y313911</a>		Door Strike Retainer
24	Y313927		INSTRUCTION LABEL
25	<a href="#">Y314062</a>		Screw, Door Hinge And Panel
26	<a href="#">314077</a>		Door Seal
27	314119	Not Available	GAS IGNITION LABEL
28	<a href="#">314286</a>		Seal For Front Panel
29	314347	<a href="#">400021-1</a>	Screw

