

Maytag LDE482 02 - DOOR



30

Maytag [Residential Maytag LDE482 Dryer Parts](#) Parts Diagram 02 - DOOR
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	Y313927			INSTRUCTION LABEL
3	306436			Door Latch Kit-W
4	314286			Seal For Front Panel
5	Y310376			Clip, Door Switch Harness
6	212982	22001650		Fastener, Spring
7	314077			Door Seal
8	314347	400021-1		Screw
9	Y305753	W10169313		Switch-Dor
10	Y314062			Screw, Door Hinge And Panel
11	Y313910			Clip, Door Liner To Outer Panel
12	Y313911			Door Strike Retainer
13	303942		Not Available	KNOB AND SCREW
14	313908L		Not Available	DOOR PANEL-ALMOND
15	304579L		Not Available	DOOR-ALMOND
"	306668L		Not Available	DOOR, ALMOND
				INNER DOOR WITH KNOB &

16	305835	Not Available	INNER DOOR WITH KNOB & SCRE
"	306676	Not Available	INNER DOOR WITH KNOB
18	Y304577	33001230	Hinge, Door
19	Y313907		Fastener, Twin
20	304595L	Not Available	FRONT PANEL-ALMOND
21	204439		Screw And Fstner Assembly

