


Maytag LDE710 08 - REAR VIEW

MODELS DE-DG110-210-410-510-610-710-810 REAR VIEW



Maytag Residential Maytag LDE710 Dryer Parts Parts Diagram 08 - REAR VIEW

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y052740	62739		Nut, Lock
2	Y201808			Converter
3	204439			Screw And Fstner Assembly
4	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
5	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	211881			Grommet, Cord Part Not Used- Gas Models Only
7	213007			Xfor Cabinet See Cabinet, Back
8	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
9	215075			Fastener, Control Panel To Console
10	301548			Clamp, Ground Wire
11	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY

12	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
13	303846	22003781		Screw, Ground Strap
14	304594			Front Panel-White
15	304594L		Not Available	FRONT PANEL-ALMOND
16	304594M	3369903		Dishrack
18	304595L		Not Available	FRONT PANEL-ALMOND
20	Y305086			Adjustable Leg And Nut
22	305190L	307104L		Top Cover Assembly
25	305193L			Console
28	305302L		Not Available	CABINET-ALMOND
30	Y310632	1163839		Screw
"	Y310632	1163839		Screw
31	311155			Ground Wire And Clamp
32	Y311270			Washer, Terminal Block
33	Y311423	489483		Screw 10-32 X 1/2
34	311484	112432		Nut
35	Y312184			Strap, Grounding
36	Y312209	W10001200		Screw
37	Y312904			Bracket, Terminal Block
38	Y312905		Not Available	COVER, TERMINAL
39	Y312951		Not Available	ACCESS COVER, BACK
40	313122			Screw - Baffle To Tumbler
41	Y313559			Screw
42	Y313561			Screw---NA
"	Y313561			Screw---NA
43	Y314137			Foot, Rubber
44	400008			Block, Terminal

the laundry company[®]

the laundry company[®]