


Maytag LDE7304AGM 01 - CABINET-FRONT (LDE7304AGM & LDG7304AGM)



Maytag Residential Maytag LDE7304AGM Dryer Parts Parts Diagram 01 - CABINET-FRONT (LDE7304AGM & LDG7304AGM)

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	305193L			Console
2	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	Y313559			Screw
3	33001166		Not Available	COVER, TOP (ALM)---NA
4	33001258	33001242		Panel, Front
5	33001254	37001047		Handle, Door
6	214354			Screw, Top Cover To Cabnt.
7	33001230			Hinge, Door
8	204439			Screw And Fstner Assembly
9	215075			Fastener, Control Panel To Console
10	Y313561			Screw---NA
"	Y310632	1163839		Screw
11	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)

12	Y314137		Foot, Rubber
13	Y305086		Adjustable Leg And Nut
14	Y052740	62739	Nut, Lock
15	213007		Xfor Cabinet See Cabinet, Back
16	33001160	Not Available	CABINET (ALM)
17	210186	3370225	Screw
18	33001168	Not Available	PLUG, SIGHT HOLE (ALM)

