


Maytag LDE7304AGM 04 - DOOR (LDE7304AGM & LDG7304AGM)



Maytag [Residential Maytag LDE7304AGM Dryer Parts](#) Parts Diagram 04 - DOOR (LDE7304AGM & LDG7304AGM)
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|---------------------------|---------------|-----------------------------|
| 1 | Y314062 | | | Screw, Door Hinge And Panel |
| 2 | 33001230 | | | Hinge, Door |
| 3 | 33001257 | 33001240 | | Door |
| 4 | 33001254 | 37001047 | | Handle, Door |
| 5 | 33001131 | | | Seal, Door |
| 6 | 33001168 | | Not Available | PLUG, SIGHT HOLE (ALM) |
| 7 | Y304578 | LA-1003 | | Door Catch Kit |
| 8 | 212982 | 22001650 | | Fastener, Spring |
| 9 | Y310376 | | | Clip, Door Switch Harness |
| 10 | Y305754 | W10169313 | | Switch-Dor |
| " | 33001508 | W10169313 | | Switch-Dor |
| 11 | 314937 | | | Seal, Front Panel |
| 12 | 33001173 | | Not Available | NUT, SPEED |
| " | 33001172 | | Not Available | SCREW, PLASTIC |
| 13 | 33001258 | 33001242 | | Panel, Front |
| 14 | 33001174 | LA-1003 | | Door Catch Kit |

| | | | |
|----|--------------------------|---------------|---------------------------------|
| 15 | 33001176 | | Cover, Hinge Hole |
| 16 | Y313910 | | Clip, Door Liner To Outer Panel |
| 17 | 204439 | | Screw And Fstner Assembly |
| 18 | 33001243 | Not Available | PANEL, INNER DOOR (W/SEAL) |
| 19 | 33001305 | | Strike, Door |

