


# Maytag LDE8500 01 - CONTROL PANEL

SECTION: CONTROL PANEL  
MODEL: DE-DG8500



Issue Date: 6/90

26

Maytag [Residential Maytag LDE8500 Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">314184</a>			Back Up Plate
2	<a href="#">214872</a>			Palnut, End Cap Note: Nut, Lamp Holder
3	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
"	<a href="#">307310</a>			Press Care Switch
4	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
"	<a href="#">307305</a>			Switch Push To Start
5	<a href="#">306916</a>			Resistor, Med Temp Elec
6	307304		Not Available	TEMP CONTROL SWITCH 3 BUTTON
"	213117	<a href="#">67006908</a>		Screw, Ice Rack
7	305205	<a href="#">694419</a>		Mini-Buzzer
"	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
8	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">204807</a>			Ground Wire, Supp. Plte To Top Cover
9	<a href="#">306545</a>			Timer

"	910708	<a href="#">488234</a>	Screw 8-32 X 1/4
10	<a href="#">214897</a>		Pad, Control Panel
11	<a href="#">210932</a>		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
"	207216	Not Available	END CAP RH
12	<a href="#">214894</a>		Fastener, End Cap
13	215821	Not Available	CAP, KNOB
14	<a href="#">312273</a>		Nut, Control Knob
15	<a href="#">315041</a>		Knob, Timer
16	<a href="#">315042</a>		Dial Skirt
17	307325	Not Available	CONTROL PANEL
18	307252	Not Available	WIRE HARNESS NA
19	207215	Not Available	END CAP LH

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>