


Maytag LDE8704ACL 02 - CONTROL PANEL



Maytag Residential Maytag LDE8704ACL Dryer Parts Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	214872			Palnut, End Cap Note: Nut, Lamp Holder
2	33001237		Not Available	PLATE, SUPPORT
3	314728	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
4	22001290			End Cap, Control Panel
"	22001288			End Cap, Control Panel
5	214894			Fastener, End Cap
6	33001084			Panel, Control
7	33001182		Not Available	SKIRT, TIMER DIAL (BLK)
8	315041			Knob, Timer
9	312273			Nut, Control Knob
10	216193		Not Available	CAP, TIMER KNOB (BLK)
11	33001184			Button
12	214897			Pad, Control Panel
13	315317	488234		Screw 8-32 X 1/4
14	33001036			Timer

15	210186	3370225	Screw
16	204807		Ground Wire, Supp. Plte To Top Cover
17	315317	488234	Screw 8-32 X 1/4
18	Y308205	33001623	Buzzer, Non-Adjustable
19	315317	488234	Screw 8-32 X 1/4
20	33001232		Not Available SWITCH, PUSH TO START
21	33001536		Harness, Wire
"	33001142		Wire Harness, Main
"	33001340		Not Available WIRE HARNESS, MAIN
22	22001267		Knob, Selector Switch
24	315317	488234	Screw 8-32 X 1/4
25	33001046		Display, Dryness Assembly
26	33001212		Board, Control-Moisture Sensor
27	315317	488234	Screw 8-32 X 1/4
28	33001102		Resistor
29	16000327		Not Available GUIDE, QUICK REF. - MAYTAG
"	33001262		Not Available MANUAL, USE & CARE

