

# Maytag LDE8706ADE 04 - DOOR



Maytag [Residential Maytag LDE8706ADE Dryer Parts](#) Parts Diagram 04 - DOOR  
 Click on the part number to view part

| Item | Original Part Number     | Replaced By               | Status        | Part Description            |
|------|--------------------------|---------------------------|---------------|-----------------------------|
| 1    | <a href="#">Y314062</a>  |                           |               | Screw, Door Hinge And Panel |
| 2    | <a href="#">33001230</a> |                           |               | Hinge, Door                 |
| 3    | <a href="#">33001240</a> |                           |               | Door                        |
| "    | <a href="#">22001817</a> |                           |               | Sheet, Sound Damper         |
| 4    | <a href="#">33001241</a> |                           |               | Handle, Door                |
| 5    | <a href="#">33001131</a> |                           |               | Seal, Door                  |
| 6    | 33001132                 | <a href="#">33002342</a>  |               | Plug, Sifht Hole            |
| 7    | Y304578                  | <a href="#">LA-1003</a>   |               | Door Catch Kit              |
| 8    | <a href="#">22001650</a> |                           |               | Fastener, Spring            |
| 9    | <a href="#">Y310376</a>  |                           |               | Clip, Door Switch Harness   |
| 10   | 33001508                 | <a href="#">W10169313</a> |               | Switch-Dor                  |
| 11   | <a href="#">314937</a>   |                           |               | Seal, Front Panel           |
| 12   | 33001487                 |                           | Not Available | NUT, SPEED                  |
| 13   | 33001486                 | <a href="#">98008544</a>  |               | Screw                       |
| "    | <a href="#">33001610</a> |                           |               | Panel, Front                |
| "    | 33001221                 | <a href="#">22001817</a>  |               | Sheet, Sound Damper         |

|    |                          |                         |                                 |
|----|--------------------------|-------------------------|---------------------------------|
| 14 | 33001174                 | <a href="#">LA-1003</a> | Door Catch Kit                  |
| 15 | <a href="#">33001175</a> |                         | Cover, Hinge Hole               |
| 16 | <a href="#">Y313910</a>  |                         | Clip, Door Liner To Outer Panel |
| 17 | <a href="#">12001341</a> |                         | Screw And Fastener Kit          |
| 18 | 33001243                 | Not Available           | PANEL, INNER DOOR (W/SEAL)      |
| 19 | <a href="#">33001305</a> |                         | Strike, Door                    |

