

This exploded view diagram illustrates the assembly of a washing machine door. The components are numbered as follows:

- 1**: Small rectangular gasket or seal.
- 2**: Small rectangular gasket or seal.
- 3**: The main door panel.
- 4**: Door handle.
- 5**: Circular gasket or seal.
- 6**: Small circular component, likely a screw or pin.
- 7**: Small rectangular component, likely a screw or pin.
- 8**: Small rectangular component, likely a screw or pin.
- 9**: Small rectangular component, likely a screw or pin.
- 10**: Small rectangular component, likely a screw or pin.
- 11**: Small rectangular component, likely a screw or pin.
- 12**: Small rectangular component, likely a screw or pin.
- 13**: Small rectangular component, likely a screw or pin.
- 14**: Small rectangular component, likely a screw or pin.
- 15**: Small rectangular component, likely a screw or pin.
- 16**: Small rectangular component, likely a screw or pin.
- 17**: Small rectangular component, likely a screw or pin.
- 18**: Circular gasket or seal.
- 19**: Small rectangular component, likely a screw or pin.

	Screw, Door Hinge And Panel
	Hinge, Door
33001240	Door
22001817	Sheet, Sound Damper
37001047	Handle, Door
	Seal, Door
Not Available	PLUG, SIGHT HOLE (ALM)
LA-1003	Door Catch Kit
22001650	Fastener, Spring

Not Available	PLUG, SIGHT HOLE (ALM)
LA-1003	Door Catch Kit
22001650	Fastener, Spring

14	33001174	LA-1003	Door Catch Kit
15	33001176		Cover, Hinge Hole
16	Y313910		Clip, Door Liner To Outer Panel
17	204439		Screw And Fstner Assembly
18	33001243	Not Available	PANEL, INNER DOOR (W/SEAL)
19	33001305		Strike, Door

