


Maytag LDG18CM 04 - CONTROL PANEL-REAR VIEW



[Maytag Residential Maytag LDG18CM Dryer Parts](#) Parts Diagram 04 - CONTROL PANEL-REAR VIEW
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	204051	22204051		Knob
002	211881			Grommet, Cord Part Not Used-Gas Models Only
003	212276	W10116760		Screw
004	212519	488234		Screw 8-32 X 1/4
005	212949	22001866		Screw, Relay
006	212950	M0227520		Screw-Tc No.6-32 X 13/16", Preform SwiTch
007	212951			Screw, No.6-32 X 1/4 Inch
008	213099			Lens For Control Panel
009	213949			Screw, No.8-18 X 5/16 Inch
010	214650			Screw For 2-4051 Knob
011	NLA		Not Available	CONTROL COVER-WHITE
012	NLA		Not Available	CONTROL COVER-HARVEST WHEAT
013	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
014	Y303204			Start Switch With Nuts

015	NLA		Not Available	CABINET-WHITE
016	NLA		Not Available	CABINET-ALMOND
017	NLA		Not Available	CABINET-HARVEST WHEAT
018	NLA		Not Available	TOP COVER-WHITE
019	NLA		Not Available	TOP COVER-ALMOND
020	NLA		Not Available	TOP COVER-HARVEST WHEAT
021	Y303420		Not Available	SELECTOR SWITCH
022	Y303445		Not Available	MAIN WIRE HARNESS
023	Y303703			Pilot Light
024	NLA		Not Available	SCREW & WASHER ASSY.
025	310557			Washer
026	Y310632	1163839		Screw
027	Y311423	489483		Screw 10-32 X 1/2
028	NLA		Not Available	BACK FOR CONTROL PANEL
029	Y312702			Knurled Nut, Start Switch
030	Y312706	422617		Nut
031	312751			Lockwasher, Start Switch
032	Y312905		Not Available	COVER, TERMINAL
033	NLA		Not Available	CONTROL PANEL
034	Y313561			Screw----NA
035	910768	M0280301		Tie Electr

