


Maytag LDG21CS 02 - REAR VIEW



Maytag Residential Maytag LDG21CS Dryer Parts Parts Diagram 02 - REAR VIEW

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	210385			Lock Nut For Adjustable Leg
003	210684			Foot, Adjustable Leg
004	NLA		Not Available	SCREW
005	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
006	211881			Grommet, Cord Part Not Used-Gas Models Only
007	213007			Xfor Cabinet See Cabinet, Back
008	301548			Clamp, Ground Wire
009	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
010	Y302699	22003428		Leg, Adjustable
011	NLA		Not Available	TOP COVER-WHITE
012	NLA		Not Available	SCREW & WASHER ASSY.
013	NLA		Not Available	CONTROL SHROUD-WHITE
014	NLA		Not Available	SPACER ASSM-WHITE

015	NLA		Not Available	CABINET-WHITE
016	304045		Not Available	CABINET-WHITE
"	NLA		Not Available	CABINET-ALMOND
017	Y305087	22003544		Adjustable Leg W/Foot And Nut
018	Y310632	1163839		Screw
019	310933	33002194		Nut, Speed
020	NLA		Not Available	HARNESS CLIP
021	311155			Ground Wire And Clamp
022	Y311270			Washer, Terminal Block
023	Y311423	489483		Screw 10-32 X 1/2
024	311484	112432		Nut
025	Y312184			Strap, Grounding
026	Y312209	W10001200		Screw
027	Y312905		Not Available	COVER, TERMINAL
028	Y312951		Not Available	ACCESS COVER, BACK
029	313122			Screw - Baffle To Tumbler
030	NLA		Not Available	FILLER STRIP
031	NLA		Not Available	COVER PLATE FOR TOP COVER
032	Y313559			Screw
033	Y313561			Screw----NA
034	NLA		Not Available	SCREW
035	911050	4312464		Screw

