


Maytag LDG22CS 02 - REAR VIEW



Maytag [Residential Maytag LDG22CS Dryer Parts](#) Parts Diagram 02 - REAR VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	204439			Screw And Fstner Assembly
003	NLA		Not Available	SCREW
004	210684			Foot, Adjustable Leg
005	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
006	211881			Grommet, Cord Part Not Used-Gas Models Only
007	213007			Xfor Cabinet See Cabinet, Back
008	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
009	301548			Clamp, Ground Wire
010	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
011	NLA		Not Available	SCREW & WASHER ASSY.
012	NLA		Not Available	SPACER ASSM-WHITE
013	NLA		Not Available	FRONT PANEL-WHITE

014	Y305087	22003544	Adjustable Leg W/Foot And Nut
015	NLA		Not Available
"	Y305190	307104	TOP COVER-ALMOND
			Top Cover Assembly
016	NLA		Not Available
			CONTROL SHROUD-WHITE
017	NLA		Not Available
			CABINET-WHITE
018	NLA		Not Available
			CABINET-WHITE
019	Y310632	1163839	Screw
020	310933	33002194	Nut, Speed
021	311155		Ground Wire And Clamp
022	Y311270		Washer, Terminal Block
023	Y311423	489483	Screw 10-32 X 1/2
024	311484	112432	Nut
025	Y312184		Strap, Grounding
026	Y312209	W10001200	Screw
027	Y312905		Not Available
			COVER, TERMINAL
028	Y312951		Not Available
			ACCESS COVER, BACK
029	313122		Screw - Baffle To Tumbler
030	NLA		Not Available
			FILLER STRIP
031	Y313559		Screw
032	Y313561		Screw----NA
033	NLA		Not Available
			TOP COVER PLATE
034	NLA		Not Available
			SCREW
035	911050	4312464	Screw

the laundry company®

the laundry company®