


Maytag LDG26CS 05 - REAR VIEW



Maytag [Residential Maytag LDG26CS Dryer Parts](#) Parts Diagram 05 - REAR VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y312951		Not Available	ACCESS COVER, BACK
002	Y201808			Converter
003	Y305086			Adjustable Leg And Nut
004	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
005	NLA		Not Available	CABINET (WHT)
006	NLA		Not Available	CONTROL COVER (WHT)
007	211881			Grommet, Cord Part Not Used-Gas Models Only
008	NLA		Not Available	PART NOT USED
009	307998L			Front Panel---NA
"	NLA		Not Available	FRONT PANEL ASSY. (WHT)
010	301548			Clamp, Ground Wire
011	311155			Ground Wire And Clamp
012	Y312184			Strap, Grounding
013	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY

014	Y052740	62739		Nut, Lock
015	311484	112432		Nut
016	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
017	305168	33002916		Power Cord, Canadian 240V
018	Y314137			Foot, Rubber
019	204439			Screw And Fstner Assembly
020	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
021	212276	W10116760		Screw
022	213007			Xfor Cabinet See Cabinet, Back
023	NLA		Not Available	SCREW & WASHER ASSY.
024	Y310632	1163839		Screw
025	Y311423	489483		Screw 10-32 X 1/2
026	Y312209	W10001200		Screw
027	313122			Screw - Baffle To Tumbler
028	Y313559			Screw
029	Y313561			Screw----NA
030	400008			Block, Terminal
031	Y312904			Bracket, Terminal Block
032	Y312905		Not Available	COVER, TERMINAL
033	307105		Not Available	COVER, TOP ASSY. (WHT)
"	NLA		Not Available	(ALM)
034	Y311270			Washer, Terminal Block

the laundry company[®]

the laundry company[®]