


# Maytag LDG27CA 02 - REAR VIEW

SECTION: REAR VIEW  
MODEL: DE-DG27CA



Issue Date: 10/90

6

Maytag [Residential Maytag LDG27CA Dryer Parts](#) Parts Diagram 02 - REAR VIEW  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
002	<a href="#">211881</a>			Grommet, Cord Part Not Used-Gas Models Only
003	<a href="#">Y313561</a>			Screw---NA
"	Y312905		Not Available	COVER, TERMINAL
004	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
005	<a href="#">Y312184</a>			Strap, Grounding
006	<a href="#">400008</a>			Block, Terminal
007	<a href="#">Y312904</a>			Bracket, Terminal Block
008	<a href="#">Y311270</a>			Washer, Terminal Block
009	311484	<a href="#">112432</a>		Nut
010	<a href="#">307104</a>			Top Cover Assembly
011	NLA		Not Available	COVER PLATE
"	<a href="#">Y313559</a>			Screw
012	NLA		Not Available	SCREW & WASHER ASSY.

013	<a href="#">213007</a>		Xfor Cabinet See Cabinet, Back
"	NLA	Not Available	CABINET (WHT)
"	Y310632	<a href="#">1163839</a>	Screw
014	310933	<a href="#">33002194</a>	Nut, Speed
015	NLA	Not Available	SUPPORT ASSY
"	Y310632	<a href="#">1163839</a>	Screw
016	<a href="#">213007</a>		Xfor Cabinet See Cabinet, Back
"	<a href="#">Y313561</a>		Screw----NA
"	NLA	Not Available	CABINET, LOWER (WHITE)
"	Y310632	<a href="#">1163839</a>	Screw
017	<a href="#">210385</a>		Lock Nut For Adjustable Leg
018	Y302699	<a href="#">22003428</a>	Leg, Adjustable
019	<a href="#">210684</a>		Foot, Adjustable Leg
020	211294	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">Y313561</a>		Screw----NA
"	Y312951	Not Available	ACCESS COVER, BACK
021	<a href="#">301548</a>		Clamp, Ground Wire
"	<a href="#">313122</a>		Screw - Baffle To Tumbler
022	<a href="#">311155</a>		Ground Wire And Clamp

