


Maytag LDG303 01 - CONTROL PANEL



Maytag [Residential Maytag LDG303 Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	214872			Palnut, End Cap Note: Nut, Lamp Holder
2	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
3	314726		Not Available	END CAP - LEFT HAND
4	214894			Fastener, End Cap
5	306484		Not Available	CONTROL PANEL
6	910708	488234		Screw 8-32 X 1/4
7	314725	33001500		Dial, Timer Indicator
8	314724			Knob For Timer
9	312273			Nut, Control Knob
10	314723	W10133501		Cap, Knob
11	314727	207927		End Cap, Control Panel
12	214897			Pad, Control Panel
13	306483			Timer
14	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

15	204807		Ground Wire, Supp. Plte To Top Cover
16	305205	694419	Mini-Buzzer
17	314184		Back Up Plate
18	306808		Not Available WIRE HARNESS
"	306587		Not Available MAIN WIRE HARNESS

