


# Maytag LDG312 01 - CONTROL PANEL



Maytag [Residential Maytag LDG312 Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
2	314177		Not Available	BRACKET FOR START SWITCH
3	<a href="#">306533</a>			Switch, Push/To/Start W/Bkt
4	<a href="#">214872</a>			Palnut, End Cap Note: Nut, Lamp Holder
5	<a href="#">210932</a>			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
6	<a href="#">214815</a>			End Cap F/Control Panel-LH
7	<a href="#">214894</a>			Fastener, End Cap
8	Y306381		Not Available	CONTROL PANEL
9	910708	<a href="#">488234</a>		Screw 8-32 X 1/4
10	314422	<a href="#">33001500</a>		Dial, Timer Indicator
11	<a href="#">314421</a>			Knob For Timer
12	<a href="#">312273</a>			Nut, Control Knob
13	215164		Not Available	CAP FOR KNOB
14	<a href="#">214816</a>			End Cap F/Control Panel-RH

15	<a href="#">214897</a>		Pad, Control Panel
16	<a href="#">305973</a>		Timer
17	211294	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
18	<a href="#">204807</a>		Ground Wire, Supp. Plte To Top Cover
19	305205	<a href="#">694419</a>	Mini-Buzzer
20	<a href="#">314184</a>		Back Up Plate
21	Y306178	Not Available	MAIN WIRE HARNESS
"	306804	Not Available	WIRE HARNESS
"	305781	Not Available	WIRE HARNESS

