


# Maytag LDG31CA 04 - ACCUMULATOR & COMPONENTS-SINGLE COIN

## MODEL DG31CM

### CM TIMER ACCUMULATOR & COMPONENTS - SINGLE COIN



- 3-30112 Switch for timer motor
- 3-30113 Timer motor
- 3-30116 Timing cam kit - 7-1/2 min. - 8 pins on cam
- 3-30117 Timing cam kit - 10 min. - 6 pins on cam
- 3-30145 Timer accumulator complete - .10
- 3-30162 Switch for time delay
- 3-30163 Coin handling mechanism
- 3-30164 Meter plate assembly
- 3-30165 Coin retainer spring and screw kit
- 3-31118 Coil spring for pawl
- 3-31121 Coil spring for detent arm
- 3-31122 Index lever and switch actuator
- 3-31147 Coil spring for coin carrier return

Maytag [Residential Maytag LDG31CA Dryer Parts](#) Parts Diagram 04 - ACCUMULATOR & COMPONENTS-SINGLE COIN

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">330112</a>			Switch For Actuator
002	<a href="#">330113</a>			Timer Motor
003	330116		Not Available	TIMING CAM - 8 PINS
004	330117		Not Available	TIMING CAM - 6 PINS
005	Y330145		Not Available	CONTA ACCUMULATOR ASSEMBLY
006	<a href="#">Y330162</a>			Switch For Time Delay
007	NLA		Not Available	COIN HANDLING MECHANISM
008	NLA		Not Available	METER PLATE ASSEMBLY
009	<a href="#">Y330165</a>			Retainer Spring And Screw Kit
010	NLA		Not Available	COIL SPRING, PAWL
011	NLA		Not Available	COIL SPRING, DETENT ARM
012	NLA		Not Available	INDEX LEVER-SWITCH ACTUATOR
013	NLA		Not Available	COIL SPRING, CARRIER RETURN